


ANTHEM SLTM

TRU•MIC TECHNOLOGY

User's Guide

C.R. Bayne

U.S. Patent Pending



A. MIC LEVEL CONTROL (Adjusts the level of the Tru • Mic relative to the level of the Element)

IMPORTANT: Setting this control correctly is vital to the sound of the Anthem system.

Play through a P.A. or acoustic amplifier while you are making adjustments. A small flat-head jeweler's screwdriver will be needed.

Your amplified tone should be well balanced and true to the acoustic sound and feel of the guitar. If it lacks clarity and top-end, increase the mic's level by turning the control clockwise. Back it off slightly if you experience excessive handling noise and/or brightness.

B. VOLUME CONTROL

Roll this wheel toward the neck to increase the volume or towards the bridge to decrease the volume.

Register this product online at www.lrbaggs.com